



INSTALLATION INSTRUCTIONS

FREIGHTLINER

Item #	Vehicle Description
FL20	FL20 Freightliner M2 - 106 SBA (Non-Raised Cab) (2002-2012)

IMPORTANT

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
 - B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
 - C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened **firmly**, they will minimize vibration and provide superior impact resistance.
 - D** To help maintain the factory finish, avoid acid wash.
-

Step

- 1 *Remove the hood support cylinder to the bumper*
- 2 *Remove factory bumper*
- 3 *Remove factory tow hooks*
- 4 *Install Herd steel bracket to truck using OE hardware*
- 5 *Reattach the hood support cylinder to the Herd steel bracket*
- 6 *Verify that all mounting locations are used*
- 7 *Attach bullbar to bracket using Herd supplied hinge bolts*
** For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.*
- 8 *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 9 *Wire driving lights to existing wiring (if applicable)*
- 10 *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 11 *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*

Eyebolts are secured in the channel with a 7/8" rubber washer. If you need to re-install the washer, insert the eyebolt into the hole, and thread a washer onto the back side of the eyebolt, approximately halfway onto the threaded part of the eyebolt.