



# INSTALLATION INSTRUCTIONS

## FREIGHTLINER

**Item #**

FL49

**Vehicle Description**

FL49 Freightliner Coronado (Non-SD) Glider - SFA (2008-2010)

---

### **IMPORTANT**

**A**

Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.

**B**

Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.

**C**

The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.

**D**

To help maintain the factory finish, avoid acid wash.

---

### **Step**

- 1 *Remove factory bumper*
- 2 *Remove tow hooks (see Picture I)*



*Picture I*

- 3** *Install the Herd steel bracket to truck using the OE hardware. Do not install the sub-mount (this part comes bolted to the back of the bracket) until after the bracket has been installed and levelled, see Picture II*



Attach after the bracket has been levelled

- 4** *Loose mount will bolt to steel bracket and truck's crossmember using Herd supplied hardware (see picture above)*
- 5** *Verify that all mounting locations are used*
- 6** *Attach bullbar to bracket using Herd supplied hinge bolts*  
*\* For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.*
- 7** *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 8** *Wire driving lights to existing wiring (if applicable)*
- 9** *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 10** *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*

*Eyebolts are secured in the channel with a 7/8" rubber washer. If you need to re-install the washer, insert the eyebolt into the hole, and thread a washer onto the back side of the eyebolt, approximately halfway onto the threaded part of the eyebolt.*