



INSTALLATION INSTRUCTIONS

INTERNATIONAL

Item # **Vehicle Description**
IN05 *International - 5600*

IMPORTANT

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
- B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
- C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
- D** To help maintain the factory finish, avoid acid wash.

Step

- 1** *Remove factory bumper*
- 2** *Remove center brace (incl. factory tow section). 4 bolts per side - see picture*
- 3** *Install Herd steel bracket to truck using OE hardware*
- 4** *Verify that all mounting locations are used*
- 5** *Attach bullbar to bracket using Herd supplied hinge bolts*
* For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.
- 6** *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 7** *Wire driving lights to existing wiring (if applicable)*
- 8** *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 9** *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*



Eyebolts are secured in the channel with a 7/8" rubber washer. If you need to re-install the washer, insert the eyebolt into the hole, and thread a washer onto the back side of the eyebolt, approximately halfway onto the threaded part of the eyebolt.