



# INSTALLATION INSTRUCTIONS

## KENWORTH

**Item #**                      **Vehicle Description**

*KW05*

*Kenworth T2000*

***THIS IS NOT TO BE INSTALLED REMOTELY WITHOUT PRIOR  
CONSENT FROM ENGINEERING***

---

### **IMPORTANT**

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
  - B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
  - C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
  - D** To help maintain the factory finish, avoid acid wash.
- 

**Step**

**1**