



INSTALLATION INSTRUCTIONS

KENWORTH

Item #

KW09

Vehicle Description

Kenworth W900B Logger SFA (1982-2014)

IMPORTANT

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
- B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
- C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
- D** To help maintain the factory finish, avoid acid wash.

Step

- 1** *Remove factory bumper*
- 2** *Remove factory tow hook*
- 3** *Remove left and right flanges (S-brackets - see pic)*
- 4** *Install Herd steel bracket to truck using OE hardware*
- 5** *Install factory towpin to bottom 4 bolts of 6 bolt pattern on main bracket face (pin moves down 1 set of bolts)*
- 6** *Install loose brace between back of Herd bracket and top of Herd bracket. See picture below for installation. This is mounted using Herd supplied bolts.*
- 7** *Verify that all mounting locations are used*
- 8** *Mount bullbar to bracket using Herd supplied hinge bolts*
- 9** *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 10** *Wire driving lights to existing wiring (if applicable)*
- 11** *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 12** *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*

