



INSTALLATION INSTRUCTIONS

KENWORTH

Item #	Vehicle Description
KW16	2010+ Kenworth W900B Wide Rad SFA (2010-2015) Revised Sept 14 2016

IMPORTANT

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
- B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
- C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
- D** To help maintain the factory finish, avoid acid wash.

Step

- 1 *Remove factory bumper*
- 2 *If there is a center piece, then remove it*



Or the truck comes with Center tow section, after removed it, reuse the factory hardware on Herd steel bracket.



- 3 *Install Herd steel bracket to truck using supplied hardware*
- 4 *Verify that all mounting locations are used*

- 5** ***Attach bullbar to bracket using Herd supplied hinge bolts***
* For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.
- 6** ***Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary***
- 7** ***Wire driving lights to existing wiring (if applicable)***
- 8** ***Insert towpin and tighten eyebolts (75-100 ft-lbs)***
- 9** ***Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.***

Eyebolts are secured in the channel with a 7/8" rubber washer. If you need to re-install the washer, insert the eyebolt into the hole, and thread a washer onto the back side of the eyebolt, approximately halfway onto the threaded part of the eyebolt.