



# INSTALLATION INSTRUCTIONS

## MACK

Item #	Vehicle Description
MK06	Mack Granite SFA (2008+) Centre Tow Pin and Twin Tow Hooks

---

### **IMPORTANT**

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
  - B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
  - C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
  - D** To help maintain the factory finish, avoid acid wash.
- 

### Step

- 1 *Remove factory bumper*
- 2 *Install Herd steel bracket onto truck using OE hardware*
- 3 *Verify that all mounting locations are used*
- 4 *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 5 *Attach bullbar to bracket using Herd supplied hinge bolts*  
*\* For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.*
- 6 *Install/wire driving lights to existing wiring (if applicable)*
- 7 *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 8 *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*