



INSTALLATION INSTRUCTIONS

MACK

Item #	Vehicle Description
MK07	Mack Pinnacle CXU

IMPORTANT

- A** Herd Bullbars are vehicle "Make & Model" specific. Use of a bullbar on a vehicle other than the model it was designed for will constitute improper use of the product and may void warranty.
- B** Unless otherwise specified, Grade 8 hardware is to be used. For the purposes of these instructions, OE hardware means the truck's original factory hardware.
- C** The drop-forged eyebolts are an integral part of the strength of Herd bullbars. When tightened firmly, they will minimize vibration and provide superior impact resistance.
- D** To help maintain the factory finish, avoid acid wash.

Step

- 1** *Remove factory bumper*
- 2** *Install Herd steel bracket onto truck using supplied hardware. With the bar bracket front face vertical, if there is gap between the underside of the truck frame and the top of the mounting bracket, insert the supplied spacers.*
- 3** *Verify that all mounting locations are used*
- 4** *Check to ensure bar is level relative to a significant feature of the truck, and readjust if necessary*
- 5** *Attach bullbar to bracket using Herd supplied hinge bolts*
** For DFLT & Defender models only: To install the hinge bolts, the bumper must be in the open (down) position to allow the bottom lip to go under and around the steel hinge.*
- 6** *Install/wire driving lights to existing wiring (if applicable)*
- 7** *Insert towpin and tighten eyebolts (75-100 ft-lbs)*
- 8** *Re-check the mounting bracket and bolts after the first 5,000km and every 3-6 months.*