



## SUPPLEMENTAL INSTALLATION INSTRUCTIONS

# PETERBILT

Item #	Part Description
1-MP-PB-HDTOW	Replaces Peterbilt part # 01-47274, provides mounting location for Herd bracket



Picture 1



Picture 2

### Step

- 1 *Remove towhook*
- 2 *Remove bolt circled in red on picture 1*
- 3 12/15/2008
- 4 *If this is fitted onto a new Herd bullbar, the holes will be on the bracket to match the holes on the bracket. If this is a retrofit, you may have to drill or enlarge the holes on the Herd steel bracket.*

You will require the following hardware to complete this installation:

- 4 *5/8" x 3" UNC Grade 8 bolts*
- 4 *5/8" UNC Grade 8 locknuts*
- 8 *5/8" Grade 8 flat washers*