

DOOR STOP

Stops the trailer door from fully opening



LATCH

Locks the door stop in place.
Provides safe access to your trailer.

BODY

Mounts to the trailer plate

CAM HANDLE

Gives you leverage you need to lock the safety device to the trailer.

PREVENT UNLOADING ACCIDENTS AND CARGO SPILLAGE IN FOUR EASY STEPS

Attach the Door Defender to the trailer plate using the Cam Handle to secure it in place. Open the trailer door, in the event that the cargo has toppled into the trailer door the door stop will prevent the door from opening. Flip the latch mechanism to release the door stop, you now have safe access to your cargo.

